





EXOSKELETON SHREDDER®

INSTRUCTIONS:

1. Press button on Shredder's Kwan-do to fire projectile.



2. Turn knob on back of Shredder's Exoskeleton elbow for sword spinning action.



3. Open hatch to insert or remove figure.



4+

Playmates
TOYS

ASST. NO. 55100
STOCK NO. 55105

Do not use projectile other than those provided by the toy.
Do not discharge in direction of people, animal or at eyes or face.
Teenage Mutant Ninja Turtles and TMNT are trademarks of Mirage Studios, Inc. Teenage Mutant
Ninja Turtles® Leonardo®, Michelangelo®, Raphael®, Donatello®, Splinter®, Shredder®, and
April O'Neil® are registered trademarks of Mirage Studios, Inc. All Rights Reserved.



WARNING: CHOKING HAZARD
Small parts. Not for Children under 3 years.