


TEENAGE MUTANT NINJA TURTLES®




5. Wind up the Radical Rotatin' Ninja Egg Knob clockwise as shown. Continue to turn the knob until you hear a "heavy" clicking sound. Caution - Do not over wind.




Hey, Dudes, I don't mind a splittin' headache, so wind me up, step back, and get ready for my explodin' Kowabunga Crakin' Egg to unleash me into an awesome Battle Ready Mutant!

6. While holding the wind up knob-in from turning, place the Crakin' Egg on a smooth flat, hard surface, let go of the egg and wait for your radical reptile to come exploding out ready for some Foot Breakin' Ninja action.



1. Push down on Turtle bud's head while holding his feet to compress him at the waist as shown. Make sure his arms are rotated forward as shown.
2. While holding him in a compressed position, carefully place him inside the left Shell Half as shown, making sure the Shell Half is facing up so he won't fall out. Also make sure his arms and weapons are inside the shell.
3. While holding the right half egg shell, turn the egg knob counter clockwise until you hear ONE click.
4. Next, locate the Pin on the Right Shell and slide the two shells together, making sure the Pin is inserted into the Hole on the Left Shell Half as shown. Carefully close the two shell halves, but make sure not to close the eggshell on your fingers!



Eggcellent! There's nothin' better than bustin' out of my egg, ready to fight the Foot. Team me up with Michaelangelo, Donatello, Raphael, and Leonardo, and release us into eggciting, eggsplooding action against the Foot Yulks. This taste of Teenage Turtle Terror will whip them into scrambled eggssile.

Notes:

1. If the egg shell halves will not stay closed, turn the knob one click counter clockwise.
2. Do not overwind the egg when the egg is closed.
3. To open the shells without winding the egg, turn the knob counter clockwise until it opens.

ASST. NO. 348090
AGES 4 AND UP

Playmates®