






Flip down the kickstand underneath the cycle to keep Leo's Camo Blitz Cycle ready for the next ride.



Load the Finger-flick Side Rockets on each side of Leo's Camo Blitz Cycle. To fire, just flick your finger on the side of each rocket.



To load the Surprise Spring-powered Missile, press into launch port in rear compartment until missile clicks into place. To fire, just press down on the back of the missile behind rear compartment.



To snap Leo into his Camo Blitz Cycle, place him into the cockpit feet first and lower him into position. Close the rear compartment and Leo becomes one with the machine using Ninja Turtleflag tactics.



WARNING: CHOKING HAZARD
Small parts. Not for Children under 3 years.

© 1998 Playmates Toys Inc. Distributed by Playmates Toys Inc. 611 Anton Blvd., Suite 600, Costa Mesa, CA 92626. Exclusively licensed by Surge Licensing. Printed in China.

ASST. NO. 33135
STOCK NO. 33136
AGES 4 AND UP

Playmates